


TFT Display Module to Raspberry pi (4-Wire SPI Interface)



== How to use ==

- 1, Install the C libraries of bcm2835, see: <http://www.airspayce.com/mikem/bcm2835/>
- 2, Change the current directory to where the Makefile and oled.c file located.
- 3, Clean the file with: make clean
- 4, Compile the file with: make
- 5, Run the demo with: sudo ./tft

REV.	DESCRIPTION OF MODIFY	MODIFY BY	DATE
A0	1'ST DESIGN	JIM	18/Mar/2025
A1			

Title EASTRISING TECHNOLOGY CO.,LTD. www.buydisplay.com

Size A	Number ER-TFTM1.65-2 (4-Wire SPI Interface)	Revision A0
Date: 18/Mar/2025	Sheet of 1	
File	Drawn By Javen	